

SB-2028 Spray Buff

1. Remove loose dirt with Ohm-Shield™ FC-4500.
2. Lightly spray small area with Spray Buff. Treat small areas at a time.
3. Buff-spray area at 1000-1500 rpm until clean and glossy. The area must be in a liquid state. Do not let floor dry prior to buffing.
4. After high speed buffing, dry mop the entire area with an untreated mop. Check the electrical resistivity. If necessary, apply one coat of OHM-Shield ESD Floor Finish.